

ОБЩЕСТВО С ОГРАНИЧЕННОЙ ОТВЕТСТВЕННОСТЬЮ
"ИНТЕРАКТИВНЫЕ ПРОМЫШЛЕННЫЕ СИСТЕМЫ"

Инструкция по запуску тестовой версии системы мониторинга
промышленного оборудования CNC-VISION,
предоставленной для проведения экспертной проверки

Москва, 2024

1. Запуск тестовой версии программы

Тестовая версия системы мониторинга промышленного оборудования CNC-VISION предоставляется в виде ссылки на удалённый доступ к инфраструктуре с развёрнутым экземпляром ПО.

Для запуска необходим компьютер с предустановленным интернет-браузером, а также наличие доступа к сети Internet.

Для запуска в адресной строке интернет-браузера необходимо ввести ссылку: [https://demo:iI\\$\(p^8gGX\\$C6~t~@demo.cnc-vision.ru/](https://demo:iI$(p^8gGX$C6~t~@demo.cnc-vision.ru/)

Затем в открывшемся окне необходимо ввести логин и пароль (рисунок 1).

Логин: admin

Пароль: admin

После этого выполнится вход в систему.

The image shows a login window titled "Вход" (Login) with a close button in the top right corner. Below the title is the instruction: "Введите логин и пароль для доступа к дополнительным функциям системы" (Enter login and password for access to additional system functions). There are two input fields: the first contains the text "admin", and the second also contains "admin" and has a small eye icon to its right. Below the input fields is a checked checkbox with the text "Запомнить меня" (Remember me). At the bottom of the form is a large teal button with the text "Войти" (Login).

Рисунок 1 – Вход в систему